

Instructions for using skis

Always store skis in a dry and dark place. Do not expose them to direct sunlight. Make sure they are not stored in a damp place or near a source of radiant heat. Never transfer and do not transport skis without adequate packaging. To transport skis, use the packages (bags) intended for this purpose. If you have a bag for 1 pair of skis, don't try to put more pairs of skis in this bag. In such an action, they could damage the skis.

Before use, check whether the skis (and bindings) are not damaged or significantly scratched. If they are damaged edges, slides or bindings, take the skis to a professional service for repair.

Ski slides should be waxed before use. Liquid or solid waxes should be used and waxing iron. Always follow the wax manufacturer's instructions. It is common for chemical spraying to destroy the edges and slides. Carving skis require fine sanding of the edges with a fine file and diamond. Leave this professional activity to a professional service. After use, the skis are always loose dry.

Edge protection

The edges of the skis are prone to rust. Therefore, it is extremely important that you leave the edges dry well before storing the skis. Always wipe the skis carefully after skiing snow and water. Always keep the skis connected with skifix tape, which ensures penetration of air between the skis, which limits the formation of surface rust on the edges of the ski. Skis nowhere do not leave stored in a ski bag or in areas with increased humidity. At to prepare your skis for the summer shutdown, you should properly wax the edges in addition to the slides skis. If you want to have rust completely under control, it's good to regularly during the season check all rust-prone areas and sand them well so that rust cannot spread spread over the edges over the summer. If you don't feel like sharpening the edges, we recommend taking your skis to a ski service. Rusting of the edges of the skis is not a defect of the product. Always sharpen skis carefully before use or use the ski service.

Always use the skis only for their intended purpose. There are several types of skis for different terrain. Never do not use the skis on terrain other than that for which they are intended.