

## Instructions for using ski boots

Ski boots are intended only for skiing. Always check the condition of the ski boots before use. Not even a skeleton the fastening of the ski boots must not be damaged. Never use ski boots if im some part is missing or they are damaged (cracked, have obvious defects). Use skis only with compatible bindings that have been properly adapted to your ski boots. On screwdrivers treat the threads of the clips with silicone oil.

When putting on ski boots, unfasten all clips (buckles, straps) and stretch them sufficiently skeleton of ski boots. After putting on the ski boot, adjust the tongue of the inner boot so that it does not press. Take care in order not to crease the inner shoe when wearing it. Fasten the clips in the order inner and up then external. Tighten the clips as needed. The leg must not be free in the ski boot and you at the same time the skier must not push.

After skiing, wipe the frame of the ski boots including the clips (buckles) with a dry cloth. Do not use chemical cleaning agents. Also dry the inner boots of ski boots. For internal do not apply any cleaning agents to the shoes. Do not dry skis or indoor boots in a straight line fire or near a source of radiant heat.

Carry skis in a bag designed for that. Put 1 pair of ski boots in your bag (always dry). Check whether the bag is damaged (torn). Store skis in a dry place. Make sure the ski boots are not in a wet environment and they are not exposed to direct sunlight.